



STT SOLUTIONS

Test Procedure Configure Eltek 60V Battery Chargers

Procedure No.: T16
Page 1 of 19
Revision: 0
Approved: F. Foley

1	ELTEK CHARGERS SET-UP	2
1.1	INITIAL SET-UP PROCESS	2
1.2	CONFIGURATION SETTINGS	3
2	WIRING AND CABLING	14
2.1	PRE INSTALLATION MODIFICATIONS	14
2.2	AC POWER WIRING	17
2.3	DC POWER WIRING	18
2.4	ALARM & TEMPERATURE PROBE WIRING.....	19

1 Eltek Chargers Set-Up

1.1 Initial Set-Up Process

- 1.1.1 Connect an Ethernet Cable into the port on the controller card of the charger, the other end of the Ethernet cable must be attached to our internal network switch.
- 1.1.2 Run the Eltek Network Utility on the Desktop (Download this from Eltek if you do not have a copy) and click on the search key located on the top left hand corner of the application. See Figure 1. Eltek Network Utility Search Screen below.



Figure 1. Eltek Network Utility Search Screen

- 1.1.3 Highlight the Controller and click on IP config button located on the bottom left hand corner and set the IP Address to 10.24.70.220, also click the DHCP box as shown in Figure 2. Eltek Network Utility IP Configuration.




Figure 2. Eltek Network Utility IP Configuration

1.2 Configuration Settings

- 1.2.1 Close the application and reopen and search again for the controller, when it's found note the IP address and in any Internet Browser type this figure into the address bar, this will permit access to the controller settings the User Name and password is admin and the Password is admin.




Figure 3. Log In Screen

- 1.2.2 On the System Configuration tab change the settings to those shown in Figure 4. Mains Configuration and Figure 5. System Voltages and make changes as per the other screen shots in:

Figure 6. System Global Settings

Figure 7. Rectifier Configuration

Figure 8. Battery Configuration

Figure 9. Battery Boost Settings

Figure 10. Battery Equalize Settings

Figure 11. Alarm Configuration SP2 Master 1. Rename Alarm A & B to Major and Minor Alarm respectively.

Figure 12. Mains Input Alarm Configuration

Figure 13. Rectifiers Alarm Configuration

Figure 14. Rectifiers Communication Alarm

Figure 15. Battery Voltage Alarm Settings

Figure 16. Battery Temperature Alarm Settings

Figure 17. Battery Quality Alarm Settings

Figure 18. Battery Output Alarm Settings

Figure 19. Battery Control Unit Alarm Settings




Figure 4. Mains Configuration




Figure 5. System Voltages





Figure 6. System Global Settings




The screenshot shows the SMARTPACK2 configuration interface for a battery charger. The left sidebar has a 'Rectifier' section selected under 'Power System'. The main panel displays the 'Rectifier Configuration' settings:

- Number of rectifiers: 2
- Suppress rectifier fail when mains is gone: Enable (dropdown: Short time)
- Over voltage shutdown (OVS) limit: 2.4000 V/cell (72.00V)
- Current limit: Enable (dropdown: 80 A)
- Emergency voltage: 66.90 V
- Generator dependent delay: Enable (dropdown: 0 minutes)
- Silence rectifier alarm: Enable
- Redundant rectifiers: 0 %

At the bottom, there are 'C' and 'S' icons, and the status bar shows 'always on' and 'Access level: Administrator'.

Figure 7. Rectifier Configuration



The screenshot shows the SMARTPACK2 configuration interface for a battery charger. The left sidebar has a 'Battery' section selected under 'Power System'. The main panel displays the 'General Battery configuration' and 'Battery contactor' settings:

General Battery configuration

- Number of banks: 1
- Description: Eltek Std
- Capacity [per string]: 60 Ah
- Number of Battery strings: 1
- Battery install date [yyyy-mm-dd]: 2014 - 2 - 14
- Battery Type: Edit battery table

Battery contactor

#	Enable	Description	Disconnect voltage [V]	Reconnect voltage [V]	Delay after disconnect [seconds]	Mains independent	Temperature dependent
1	<input type="checkbox"/>	LVBD	54.00	60.25	0	<input type="checkbox"/>	<input type="checkbox"/>

At the bottom, there are 'C' and 'S' icons, and the status bar shows 'always on' and 'Access level: Administrator'.

Figure 8. Battery Configuration




Figure 9. Battery Boost Settings




Figure 10. Battery Equalize Settings




Figure 11. Alarm Configuration SP2 Master 1. Rename Alarm A & B to Major and Minor Alarm respectively.




Figure 12. Mains Input Alarm Configuration




Figure 13. Rectifiers Alarm Configuration




Figure 14. Rectifiers Communication Alarm

SMARTPACK2
Sw#:405006.009 Rev:2.3

Battery Alarm Configuration

#	Edit	Description	Enable	Status
1	edit	BatteryVoltage	<input checked="" type="checkbox"/>	✓
2	edit	BatteryCurrent	<input type="checkbox"/>	✗
3	edit	BatteryTemp	<input checked="" type="checkbox"/>	✓
4	edit	BatteryLifeTime	<input type="checkbox"/>	✗
5	edit	LVBD	<input type="checkbox"/>	✗
6	edit	BatteryQuality	<input checked="" type="checkbox"/>	✓
7	edit	BatteryTotCap	<input type="checkbox"/>	✗
8	edit	BatteryRemCap	<input type="checkbox"/>	✗
9	edit	BatteryTimeLeft	<input type="checkbox"/>	✗
10	edit	DeltaStringCurr	<input type="checkbox"/>	✗
11	edit	BatteryUsedCap	<input type="checkbox"/>	✗
12	edit	Ah Charged	<input type="checkbox"/>	✗
13	edit	Ah Discharged	<input type="checkbox"/>	✗
14	edit	BadTestResults	<input type="checkbox"/>	✗

BatteryBank 1

BatteryVoltage

Description	Value	Unit
Alarm Monitor	<input checked="" type="checkbox"/> Enable	
Manual reset	Disabled	
Hysteresis	0.10	Volt DC
Time delay	0 seconds	
Monitor Description	BatteryVoltage	
Event	Volt DC	Alarm Group
Major High	71.25	Major Alarm
Minor High	71.00	Minor Alarm
Minor Low	60.00	Minor Alarm
Major Low	57.87	Major Alarm

Figure 15. Battery Voltage Alarm Settings

SMARTPACK2
Sw#:405006.009 Rev:2.3

Battery Alarm Configuration

#	Edit	Description	Enable	Status
1	♂	BatteryVoltage	<input checked="" type="checkbox"/>	✓
2	♂	BatteryCurrent	<input type="checkbox"/>	✗
3	♂	BatteryTemp	<input checked="" type="checkbox"/>	✓
4	♂	BatteryLifeTime	<input type="checkbox"/>	✗
5	♂	LVBD	<input type="checkbox"/>	✗
6	♂	BatteryQuality	<input checked="" type="checkbox"/>	✓
7	♂	BatteryTotCap	<input type="checkbox"/>	✗
8	♂	BatteryRemCap	<input type="checkbox"/>	✗
9	♂	BatteryTimeLeft	<input type="checkbox"/>	✗
10	♂	DeltaStringCurr	<input type="checkbox"/>	✗
11	♂	BatteryUsedCap	<input type="checkbox"/>	✗
12	♂	Ah Charged	<input type="checkbox"/>	✗
13	♂	Ah Discharged	<input type="checkbox"/>	✗
14	♂	BadTestResults	<input type="checkbox"/>	✗

BatteryBank 1

BatteryTemp

Description	Value	Unit
Alarm Monitor	<input checked="" type="checkbox"/> Enable	
Manual reset	Disabled	
Hysteresis	1	Celsius
Time delay	12 seconds	
Monitor Description	BatteryTemp	

Event	Celsius	Alarm Group
Major High	40	Major Alarm
Minor High	30	Minor Alarm
Minor Low	-5	Minor Alarm
Major Low	-10	Major Alarm

Figure 16. Battery Temperature Alarm Settings

SMARTPACK2
Sw #:405006.009 Rev:2.3

Battery Alarm Configuration

#	Edit	Description	Enable	Status
1	⊕	BatteryVoltage	<input checked="" type="checkbox"/>	✓
2	⊕	BatteryCurrent	<input type="checkbox"/>	✗
3	⊕	BatteryTemp	<input checked="" type="checkbox"/>	✓
4	⊕	BatteryLifeTime	<input type="checkbox"/>	✗
5	⊕	LVBD	<input type="checkbox"/>	✗
6	⊕	BatteryQuality	<input checked="" type="checkbox"/>	✓
7	⊕	BatteryTotCap	<input type="checkbox"/>	✗
8	⊕	BatteryRemCap	<input type="checkbox"/>	✗
9	⊕	BatteryTimeLeft	<input type="checkbox"/>	✗
10	⊕	DeltaStringCurr	<input type="checkbox"/>	✗
11	⊕	BatteryUsedCap	<input type="checkbox"/>	✗
12	⊕	Ah Charged	<input type="checkbox"/>	✗
13	⊕	Ah Discharged	<input type="checkbox"/>	✗
14	⊕	BadTestResults	<input type="checkbox"/>	✗

BatteryBank 1

BatteryQuality

Description	Value	Unit
Alarm Monitor	<input checked="" type="checkbox"/> Enable	
Manual reset	All Levels	
Hysteresis	0	%
Time delay	0 seconds	
Monitor Description	BatteryQuality	

Event	%	Alarm Group
Minor Alarm	80	Minor Alarm
Major Alarm	75	Major Alarm

Figure 17. Battery Quality Alarm Settings




Figure 18. Battery Output Alarm Settings



Figure 19. Battery Control Unit Alarm Settings

2 Wiring and Cabling

2.1 Pre Installation Modifications

- 2.1.1 The following modifications must be completed before the unit is put into service, these modifications are necessary to isolate the DC terminals from the earth.
- 2.1.2 The first modification is to remove the two resistors shown in Figure 20. Remove Resistors
The resistors are located beside the CAN Bus connection at the rear of the unit.




Figure 20. Remove Resistors

- 2.1.3 The second modification is to run an earth wire 4mm² from the terminal adjacent to the CAN Bus connector block on the rear (see Figure 21. Run Earth Wire) and connect it to the top of Terminal 1 as shown in Figure 24. AC Power Wiring.




Figure 21. Run Earth Wire

- 2.1.4 The third modification is to remove the jumper link as shown in Figure 22. Remove Jumper. To access this link remove the green connector and open the screw as shown in Figure 23. Smartpack 2 Access Screw.




Figure 22. Remove Jumper



Figure 23. Smartpack 2 Access Screw

2.2 AC Power Wiring

2.2.1 Use the jumpers that come with the unit to connect 2, 3 & 4, and 5, 6 & 7 as shown in Figure 24. AC Power Wiring.




Figure 24. AC Power Wiring

2.3 DC Power Wiring

2.3.1 The DC Wiring is connected to the Load Terminals. It is shown in Figure 25. DC Wiring




Figure 25. DC Wiring

2.4 Alarm & Temperature Probe Wiring

2.4.1 The temperature and alarm contact wiring are shown in Figure 26. Temperature Sensor Wiring and Figure 27. Alarm Wiring.




Figure 26. Temperature Sensor Wiring



Figure 27. Alarm Wiring

Figure 28. Chassis & DC Negative Earth